

Automatischer Desinfektionsmittelspender



Automatischer Desinfektionsmittelspender

Passend für die Flaschenformen aller wichtigen Desinfektionsmittel-Hersteller.

Art.-Nr.: DMS5-A für 500 ml-Flaschen
 DMS10-A für 1.000 ml-Flaschen

Vor der Montage beachten:

Packen Sie den Karton aus und achten darauf, dass folgende Teile enthalten sind:

- 1 Spender mit montierter Rollerpumpe (mit Jet-Tip)
- Rückwand zur Wandmontage (nicht nötig, wenn bereits eine passende Rückwand eines manuellen Spenders vorhanden ist)
- Tropfschale (zum Aufstecken nach der Montage) + 1 Ersatzpumpe (mit Spray-Tip)
- 1 Beutel mit 1 Schlüssel und je 4 Schrauben und Dübeln
- 4 Stück 1,5V AA-Batterien (um die angegebene lange Laufzeit (> 40.000 Zyklen) zu erreichen, sollten Sie nur frische Markenbatterien verwenden)

Für Installation und Inbetriebnahme beachten Sie bitte die rückseitigen Piktogramme.

Touchless Disinfectant Dispenser

Usable for bottles of all important disinfectant producers

REF-No: DMS5-A for 500 ml bottles
 DMS10-A for 1.000 ml bottles

Before mounting the dispenser:

Unpack the box and check whether it contains following:


- 1 dispenser with mounted roller pump (with jet tip)
- 1 wall mounting part (not needed when dispenser can be mounted on existing wall plate of a manual disinfectant dispenser)
- 1 dripping tray (to be attached after mounting) + 1 spare pump (with spray tip)
- 1 bag with 1 key and 4 screws and dowels each
- 4 pieces 1,5V AA batteries (to reach the long operating time of > 40.000 cycles please use fresh batteries only)

For installation and initial operation please follow the back side pictograms.


Automatischer Desinfektionsmittelspender

Seite 2


1




2




3




4




5



6




7



Pumpentausch
pump replacement

8




9




10

Auslesen gespeicherter Daten
reading of memorised data



Volumeneinstellung
volume adjustment

11



LED leuchtet blau = Spender arbeitet
LED glows blue = dispenser working
LED leuchtet rot = Batterien tauschen
LED glows red = change batteries